





























Warning Warnings: Dos and Don'ts IN DEATH. ALWAYS INSTALL E-SAPI PLATE STRIKEFACE TOWARD ENEMY AND SOFT ARMOR AGAINST BODY. SAPI AND SOFT ARMOR MUST BE USED TOGETHER. ALWAYS LOOSEN ONE SIDE OF THROAT GUARD WHEN TRAVELING OVER WATER. **ENSURE CASUALTY IS COVERED BY BODY ARMOR DURING** BATTLE TRIAGE AND MEDEVAC DO NOT BRIDGE FRONT AND REAR CARRIER AT SHOULDERS WITH COMM CABLE, HYDRATION TUBE OR OTHER GEAR. DO NOT BRIDGE CUMMERBUND AND BACK CARRIER FLAP WITH MOLLE GEAR (FOR EXAMPLE, POUCHES). DO NOT LEAVE GAPS AT SIDE OF VEST UNDER CUMMERBUND. COMM WIRING/HYDRATION DO NOT FIT FRONT E-SAPI PLATES MORE THAN ONE INCH SYSTEM HOSES ACROSS BELOW COLLARBONE. SHOULDER WILL HINDER OR DO NOT USE MTV IN CHLORINATED SWIMMING POOL. **NEGATE QUICK-RELEASE.** DO NOT ATTEMPT TO REPAIR ARMOR. USE OF DAMAGED ARMOR CAN RESULT IN SERIOUS INJURY OR DEATH.

